


## HOTWIND S ACCESSORIES

### Tubular nozzle for HOTWIND S

Tubular nozzle, push-fit (a x b x c)



105.917: 303 x 153 x 6 mm

105.907: 354 x 204 x 4.5 mm

105.919: 456 x 306 x 3 mm


107.253: 700 x 550 x 1.7 mm

114.136: 795 x 655 x 1.5 mm

105.906: 1100 x 1000 x 4 mm

### Sieve reflector for HOTWIND S

Sieve reflector, push-fit (a x b)



106.143: 45 x 75 mm

107.329: 76 x 75 mm

107.336: 110 x 152 mm




### Round nozzle for HOTWIND S

107.245: Round nozzle, push-fit d = 40 mm



### Flange connector for HOTWIND S

107.246: Flange connector, push-fit on protection tube



### Extension nozzle for HOTWIND S

107.247: Extension nozzle, push-fit (a x b) 200 x 45 mm




### Stainless steel filter for HOTWIND S

107.248: Stainless steel filter, push-fit, can be cleaned, for continuous operation

### Wide slot nozzle for HOTWIND S

Wide slot nozzle, push-fit (a x b)



107.260: 85 x 15 mm

107.259: 150 x 12 mm




105.977: 200 x 9 mm

107.263: 250 x 12 mm

107.262: 300 x 4 mm

105.992: 400 x 4 mm

105.991: 500 x 4 mm

**Angled nozzle for HOTWIND S****107.265: Angled nozzle, push-fit (a x b) shank length  
120 x 112 mm****Sieve reflector for HOTWIND S****107.335: Sieve reflector ø 150mm, push-fit****Shell reflector for HOTWIND S****Shell reflector, push-fit (a x b)****107.342: 400 x 50 mm****106.174: 400 x 65 mm****106.175: 400 x 80 mm****Flange connector for HOTWIND S****125.317: Flange connector, push-fit, a = 90 mm****Thermo couple holder for HOTWIND S****133.517: Thermo couple holder**