

## TRIAC DRIVE ACCESSORIES



### Pressure roller for TRIAC DRIVE

**115.274: Pressure roller 12 mm**

**115.176: Pressure roller 30 mm**

**115.186: Pressure roller 38 mm**



### Guide handle for TRIAC DRIVE

**115.284: Guide handle**



### Single supporting carrier for TRIAC DRIVE

**115.276: Single supporting carrier**



### Double supporting carrier for TRIAC DRIVE

**115.275: Double supporting carrier**



### Overlap welding nozzle with/without grip, inside push-fit on TRIAC DRIVE

**115.701: Overlap welding nozzle 30 mm, without grip, inside, push-fit**

**115.279: Overlap welding nozzle 30 mm, with grip, inside, push-fit**

**115.703: Overlap welding nozzle 38 mm, without grip, inside, push-fit**

**115.281: Overlap welding nozzle 38 mm, with grip, inside, push-fit**

**115.699: Overlap welding nozzle 12 mm, without grip, inside, push-fit**

**115.283: Overlap welding nozzle 12 mm, with grip, inside, push-fit**

### Overlap welding nozzle with/without grip, outside push-fit on TRIAC DRIVE



**115.702: Overlap welding nozzle 38 mm, without grip, outside, push-fit**

**115.280: Overlap welding nozzle 38 mm, with grip, outside, push-fit**

**115.700: Overlap welding nozzle 30 mm, without grip, outside, push-fit**

**115.278: Overlap welding nozzle 30 mm, with grip, outside, push-fit**

**115.698: Overlap welding nozzle 12 mm, without grip, outside, push-fit**

**115.282: Overlap welding nozzle 12 mm, with grip, outside, push-fit**